



REV	ECO	DATE	DESCRIPTION	DB
A	3968	14-Nov-08	RELEASE TO PRODUCTION	DMD




STEP BY STEP PACKAGING INSTRUCTIONS:

1. PLACE FOUR OUTER FOAM CORNERS INSIDE BOTTOM SHIPPING CONTAINER AS SHOWN.
2. PLACE BOX INSIDE SHIPPING CONTAINER ON TOP OF OUTER FOAM CORNERS AS SHOWN.
3. PLACE BOTTOM CENTER FRAME FOAM, FRONT ENDCAP, AND BOTTOM REAR ENDCAP INSIDE LASER BOX.
NOTE: BOTTOM CENTER FRAME PIECE SHOULD BE AGAINST FRONT MOUNTING RAIL TO ALIGN WITH CENTER BRACE CUTOUTS.
4. FIT LENS COVER ONTO FRONT OF LASER AND PLACE LASER INSIDE FOAM CAVITIES AS SHOWN, MAKING SURE FRONT OF LASER IS ON THE LEFT SIDE.
5. PLACE TOP CENTER FRAME FOAM AND TOP REAR ENDCAP OVER LASER AND SECURE INTO BOTTOM FOAM NOTCHES AS SHOWN.
6. FIT CENTER BRACE OVER LASER AS SHOWN.
7. CLOSE AND SEAL BOX AS REQUIRED.
8. PLACE FOUR OUTER FOAM CORNERS ON OUTSIDE CORNERS OF LASER BOX.
9. COVER WITH TOP SHIPPING CONTAINER AND SECURE AS REQUIRED.
10. DO NOT SHIP WITH KEY IN SWITCH TO AVOID DAMAGE TO KEYSWITCH.
11. WRITE SYNRAD RETURN AUTHORIZATION NUMBER ON OUTSIDE OF SHIPPING BOX.



IMPORTANT NOTE: FAILURE TO PROPERLY PACKAGE LASER USING SYNRAD SHIPPING BOX AND FOAM/CARDBOARD INSERTS AS SHOWN MAY VOID WARRANTY. CUSTOMERS MAY INCUR ADDITIONAL REPAIR CHARGES DUE TO SHIPPING DAMAGE CAUSED BY IMPROPER PACKAGING.

TOLERANCES UNLESS NOTED:		PROPRIETARY THIS DRAWING IS PROPRIETARY TO SYNRAD INC. AND SHALL NOT BE USED OR DISCLOSED IN WHOLE OR IN PART WITHOUT WRITTEN PERMISSION OF SYNRAD INC.		 SYNRAD INC. 4600 Campus Place Mukilteo, WA 98275 Phone: (425)349-3500 Fax: (425)349-3667	
.x = ± 0.1	ANGLE = ± 0.5°				
.xx = ± 0.01					
.xxx = ± 0.005		DESCRIPTION: PACKAGING, FENIX-FLYER			
MATERIAL: SEE BOM		PART NUMBER: 900-19882-01	DWG/FILE NUMBER: 900-19882-01		
FINISH:		SHEET 1 of 1	ENG: .	DRAWN BY: D. DUVALL	DATE: 14-Nov-08
		UNITS: Inches	CATEGORY: I	CHECKED BY: <i>[Signature]</i>	DATE: 3/18/2009
		SIZE: B	FINISH CLASS: .	APPROVED BY: <i>[Signature]</i>	DATE: 3/18/09